

Digital Storage Oscilloscope

1GSa/s, 200MHz, 1CH Waveform Generator

DSO2000 Series



Feature

- 200/100/70MHz Bandwidth; 1GSa/s Sample Rate;
- 2 Channel Oscilloscope; 40K Record Length;
- 7 inch 64K color LCD display, Resolution 800x480;
- 32 kinds of Automotive measurement, with FFT function;
- 25MHz Arbitrary waveform output (Sine wave up to 75MHz);
- Powerful trigger function: Video, Edge, Pluse Width, Slope, Overtime, Alternate Trigger.

Specification

	Model	DSO2200	DSO2100	DSO2070	
Horizontal	Bandwidth	200MHz	100MHz	70MHz	
	Sampling Rate Range		1GSa/s		
	Equivalent Sample Rate		25GSa/s		
	Memory Depth (Sample Points)		40K		
	SEC/DIV Range		2ns/div~80s/div		
	Delay Time Accuracy	±50ppm in any ≥1ms time intervals			
	Delta Time Measurement	Single-shot, "sampling" mode, ± (1 sampling interval + 100ppm × readings + 0.6ns)			
Vertical	Accuracy (full bandwidth)	> 16 times above average, ± (1 sampling interval + 100ppm × readings + 0.4ns)			
	A/D Converter	8-bit resolution, each channel sampled simultaneously			
	VOLTS/DIV Range	2mV/div~10V/div at input BNC			
	Position Range	±50V(5V/div); ±40V(2V/div~500mV/div); ±2V(200mV/div~50mV/div); ±400mV(20mV/div~2mV/div)			
	Rise Time at BNC	1.7ns	3.5ns	5ns	
	DC Gain Accuracy	±4% for Sample or Average acquisition mode, 5mV/div to 2mV/div ±3% for Sample or Average acquisition mode, 5V/div to 10mV/div			
	Trigger	Trigger Sensitivity(Edge Trigger Type)	DC(Intelnal): 1div from DC to 10MHz, 1.5div from 10MHz to 100MHz, 2div from 100MHz to 200MHz; DC(EXT): 200mV from DC to 100MHz, 350mV from 100MHz to 200MHz; DC(EXT/5): 1V from DC to 100MHz, 1.75V from 100MHz to 200MHz; AC: Attenuates signals below 10Hz; HF Reject: Attenuates signals when above 80KHz; LF Reject: The same as DC coupling limit when frequency above 150KHz; Attenuates signals when below 150KHz.		
Trigger Level Range		CH1, CH2: ±8 divisions from center of screen; EXT: ±1.2V; EXT/5: ±6V			
Typical accuracy for signals having rise and fall time ≥ 20ns)		CH1, CH2:±(0.2div × V/div) (within ±4 divisions from center of screen); EXT: ±(6% of setting+40mV); EXT/5: ±(6% of setting+200mV)			
Holdoff Range		100ns - 10s			
Set Trigger Level to 50% (typical)		For the input signals ≥ 50Hz			
Trigger Type		Video, Edge, Pluse Width, Slope, Overtime, Alternate Trigger.			
Normal, Peak Detect		Upon single acquisition on all channels simultaneously			
Average		After N acquisitions on all channels simultaneously, N can be set to 4, 8, 16, 32, 64 or 128			
Input		Input Coupling	DC, AC or GND		
		Input Impedance, DC coupled	1MΩ±2% for 20pF±3 pF		
	Probe Attenuation	1X, 10X,			
	Supported Probe Attenuation Factor	1X, 10X,100X, 1000X			
Measurement	Max. Input Voltage	CAT I and CAT II: Installation type: 300VRMS(10×); CAT III: 150VRMS(1×)			
	Cursors	The difference between voltage cursors ΔV; The difference between time cursors ΔT; Reciprocal of ΔT in Hertz (1/ΔT).			
	Automatic	Frequency, Period, Mean, Pk-Pk, Cyclic RMS, Minimum, Maximum, Rise time, Fall Time, +Pulse Width, -Pulse Width, Delay1-2Rise, Delay1-2Fall, +Duty, -Duty, Vbase, Vtop, Vmid, Vamp, Overshoot, Preshoot, Preiod Mean, Preiod RMS, FOVShoot, RPREShoot, BWIDTH, FRF, FFR, LRR, LRF, LFR, LFF			
Arb.Waveform Generator	Waveform Frequency	DC-25MHz (Sine wave up to 75M);			
	Waveform Depth	2KSa;			
	Frequency Resolution	0.1%;			
	Vertical Resolution	12bit;			
	Frequency Stability	<30ppm;			
	DAC Clock	2K~200MHz adjustable;			
Other	Output Impedance	50Ω			
	Display	7 inch 64K color LCD; 800x480 pixels; Adjustable (16 gears) with the progress bar			
	Voltage	100-120VACRMS(±10%),45Hz to 440Hz, CAT II ; 120-240VACRMS(±10%),45Hz to 66Hz, CAT II			
	Power	< 30W			
	Fuse	2A, T rating, 250V			
Size & Weight	313mm(L)x108mm(W)x142mm(H); 2.08KG(without Packing)				