



SPE15 Series

Single Output Power Supply

- Ultra-thin design, portable and easy to use
- 500W constant power output with 0.05% high-precision voltage and current control
- Full digital control with comprehensive protection: OVP/ OCP/ OTP
- Power-on auto output setting, ideal for unattended applications
- CV (Constant Voltage) / CC (Constant Current) modes
- Built-in discharge circuit to eliminate residual high voltage at shutdown
- List waveform output with up to 10 programmable timing steps
- 4 sets of memory presets for quick recall, enabling easy use in factory and production line environments
- Supports programmable output via PC software, providing flexible solutions for diverse testing needs.
- Versatile interfaces: USB device, optional RS485/RS232, optional LAN; supports Modbus and SCPI protocols for industrial process control and centralized network control
- 2.8-inch color IPS LCD display

+ Specifications

The instrument must be operated continuously for more than 30 minutes at the specified operating temperature to achieve the following specifications.

Model		SPE15054	SPE15105
Rated Output (0°C-40°C)	Voltage	0 - 150V	0 - 150V
	Current	0 - 5A	0 - 10A
	Power	400W	500W
Input Characteristics	Supply Voltage	100V- 240V	
	Input Frequency	45- 65Hz	
	Input Fuse	250V, F10A	
Regulation (CV)		Load: $\leq 20\text{mV}$, Line: $\leq 20\text{mV}$	
Regulation (CC)		Load: $\leq 10\text{mA}$, Line: $\leq 10\text{mA}$	
Ripple & Noise		Voltage (Vp-p): $\leq 100\text{mVpp}$, Current (rms): $\leq 30\text{mA}$	
Setting Resolution		10mV/1mA	
Readback Resolution		10mV/1mA	
Setting Accuracy		Voltage: $\leq 0.05\% \pm 20\text{mV}$, Current: $\leq 0.05\% \pm 20\text{mA}$	
Readback Accuracy		Voltage: $\leq 0.05\% \pm 20\text{mV}$, Current: $\leq 0.05\% \pm 20\text{mA}$	
Transient recovery time (10%- 100% rated load)		$\leq 5.0\text{ms}$	
OVP / OCP / OTP		0 - 155V / 0 - 6A / 85°C	0 - 155V / 0 - 11A / 85°C
Temperature coefficient of output		Voltage: 100ppm/°C, Current: 200ppm/°C	
Temperature coefficient of readback value		Voltage :100ppm/°C, Current: 200ppm/°C	
Display	Display Type	2.8-inch Color LCD Display (IPS Panel)	
	Resolution / Color	240 x 320 pixels / 65536 color,TFT	
Temperature		Working Temperature: 0°C- 40°C; Storage Temperature: -20°C ~ 60°C	
Relative Humidity		$\leq 90\% \text{RH}$; no condensation	
Height		2,000 meters	
Cooling		Fan cooling, temperature intelligent speed control	
Communication Port		USB, DB9: RS232/RS485(optional), LAN (optional), compatible with the SCPI communication protocol	
Dimension		82mm(W)× 142mm(H)×226mm(D)	
Weight		Approx. 1.6kg	

* Noise bandwidth 20MHz, ripple bandwidth 1MHz, connect 10uF electrolytic capacitor in parallel with 0.1uF ceramic capacitor to the output terminal for testing.

Specifications subject to change without prior notice.

+ Accessories The accessories subject to final delivery.



Power Cord



User Manual



USB Cable



Fujian Lilliput Optoelectronics Technology Co., Ltd.

No. 19, Heming Road, Lantian Industrial Zone Zhangzhou 363005 P.R. China
Tel : +86.596.213.0430 E-mail :info@owon.com.cn www.owon.com